




Thermal Printer -DOS Bill Not Come

PrintXML Bill Not Working

Step1: First Check Test Print Coming or Not In Printer

Control Panel->All Control Panel Items->Devices And Printers



1 → Right Click On Printer And Select Printer Properties

2 → Click Print Test Page




3 → Click Close

If the Test Page is not coming then the issue is with Printer Side. If Print is coming follow the below steps.

PrintXML Bill Not Working

Step2: Check The Port In Both Printer And EXE

Control Panel->All Control Panel Items->Devices And Printers





1 → Click Printer Properties

2 → Click Ports

3 → Note Down The Port is "LPT "or "USB"

PrintXML Bill Not Working




In EXE Press "CTRL+SHIFT+F1"



- 1 → Verify the PrintDos mode is enabled.
- 2 → Click Counter
- 3 → Confirm that the DosPrint value is 1.

PrintXML Bill Not Working

EXE Icon->Open File Location





1 → Right Click And Select Open File Location

2 → Click Bill

3 → Right Click And Select Edit

PrintXML Bill Not Working



1 → Right Click And Select Edit Option

2 → Write Pause In Notepad And Save

3 → Now Run The Saved File



If its display any error it is a printer issue and if it display Success, check the steps above.