

How to Solve Thermal Printer-Windows Not Come



How to Fix Bill not Coming Issue (Ctrl +H)



Step1: If bill not printing when you press "Ctrl+H", first go to device and printers set Microsoft XPS Document Writer



Step2: Go to c drive -->Kassapos-->Logs find error_